



# iPod Mini Bottom Bezel Replacement

Written By: iRobot



## INTRODUCTION

The plastic part on the bottom of the iPod.



### TOOLS:

- [Flathead 3/32" or 2.5 mm Screwdriver](#) (1)



### PARTS:

- [iPod Mini Bottom Bezel](#) (1)

## Step 1 — Bottom Bezel



- Carefully insert a small flathead screwdriver in the seam between the metal casing and white plastic bottom. Use the screwdriver to pry up the white plastic bottom bezel. Be careful not to damage the soft plastic with your screwdriver.

## Step 2



- A small pair of snap ring pliers is the easiest tool to remove the metal retaining bracket.
- You can also use a flathead screwdriver to pry out the metal retaining bracket beneath the bottom bezel as shown. You can free the bracket by first pushing in the metal arms on the corners and then lifting the bracket.

## Step 3



- Lift the metal retaining bracket out of the iPod.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 06:02:31 PM.